

EZ-Set Mounting Block Instructions for Use

Box Newel

Hollow center

1. Position EZ-Set mounting block as shown in picture.

2. Apply construction adhesive to the bottom of EZ-Set Mounting block.

3. Use enclosed mounting bolts to securely fasten the EZ-set mounting block to the sub floor.

4. Lower newel over the top of EZ-Set mounting block and fasten with 2 screws per side separated by a minimum of 4" in height.

5. It is the carpenters responsibility to ensure the newel is secured to meet code requirements. EZ-set is supplied for convenience only. No strength tests have been done on this installation.

Ez-set mounting block positioned off center as per instructions

