

PermaFlashing Installation Instructions

Note: flashing is available only with round tapered & square non-tapered columns and tuscan cap & base.

1. Complete steps 1 and 2 of the “Round or Square PermaCast Installation Instructions” included with the column! Note that you need to subtract 1/8” from overall height for the PermaFlashing bracket.



2. Attach PermaFlashing Bracket to soffit with provided screws. Circular notch will face substrate and must have at least 75% contact with soffit or beam.



3. Slip base over top of column shaft and allow to slide to base of shaft. Slip cap over shaft and allow to rest on neck mold. Apply non-acetone construction adhesive to top and bottom surfaces of column.

4. Continue with step 5 of the “Round or Square PermaCast Installation Instructions” included with the column.

Note 1: Position column in place by fitting the top of the column around the circular notch on the PermaFlashing bracket as load is lowered.

Note 2: Column angle brackets are included in cap and base box.



<http://store.bbwood.com>

1-216-292-6555