THE CLASSIC ROUND ALUMINUM COLUMN

Classic Round Columns have been designed and manufactured to be easy on the eyes, and provide a lifetime of structural integrity.

Note: To wrap an existing post, round columns may be modified with split caps and bases.

ASSEMBLY

Classic Columns are straight, made in sections, each stave or section having a small and a large curved hook, which interlocks to the adjoining section. Flange-type caps and bases slip over the columns to complete the unit.

STEP 1

Measure opening, cut column staves 1/8" longer.

STEP 2

Hook staves together, small hook joins large hook.

STEP 3

Hook all staves together except one, slide remaining stave into place.

STEP 4


Put cap and base on column, set in place and plumb with a level. Let weight down on column.


STEP 5


Slide cap and base into place and tighten set screws.

"Anchor Clips" are available when needed or required.

DIMENSION DATA IN INCHES					
Column Dia.	# Staves in whole column	# Staves in 1/2 column	Column O.D.	Column I.D.	
6"	3	2	5 3/4	4 15/16	
8"	3	2	7 5/8	6 13/16	
10"	4	2	9 9/16	8 3/4	
12"	5	3	11 7/16	10 5/8	







Available Sizes

Size	Size
6" x 8'	
6" x 9'	
6" x 10'	
8" x 8'	
8" x 9'	
8" x 10'	
10" x 8'	
10" x 9'	
10" x 10'	
12" x 8'	
12" x 9'	
12" x 10'	
12" x 12'	

ROUND COLUMNS COMPRESSION LOAD TEST RESULTS

Column Dia.	# of Staves	Load in Pounds
6"	3	22,000
8"	3	20,000
10"	4	26,000
12"	5	26,000