

Square PermaCast® Panel and Neck Molding

Special Neck Mold Instructions for Scamozzi, Greek Ionic and Roman Ionic Capitals for Square PermaCast Columns

Omitting neck mold - Because of the beaded rim at the base of these capitals, they may be installed without neck mold. The beaded edge serves the same purpose aesthetically as a neck mold. Standard installation instructions for capitals should be followed, omitting references to neck mold.

Using neck mold - If neck mold is to be used, it should be coped to fit around the scrolls of the capital. See appropriate illustration below.

